

ductFIT® | 50

ceiling



Air and Surface Disinfection Unit

Designed for areas without air ducts, The ductFIT®50 ceiling can cover up to 50m² with a single unit, it includes its own fan and can operate completely independently from the Air conditioning system. It includes **ductFIT** to eliminate up to 99.9% of all viruses and bacteria and **HEPA filtration** system to eliminate particles and other contaminants.

Description

- Independent air purification system
- Discrete and quiet
- 100 - 270 volt optional installation
- Easy Installation
- Low maintenance

Applications

- Small offices
- Nursing homes
- Hotel rooms, small clubs
- Hospitals
- Gyms

Specifications

- Electrical: 220 V
- Power: <120 W
- Weight: 22 Kg
- Dimensions: 63cm L x 95cm W x 27cm H
- CADR: 800m³/h (HEPA & ductFIT)
- Noise: < 48dB

Installation

CleanAir Spaces' ductFIT®100 Ceiling can be installed in any open ceiling system or it can be ducted and concealed above technical or construction ceiling.

1 Unit may be wired into a 220 volt connection.

2 The unit needs to be fixed to the ceiling with 4 anchors.

3 Unit can work 100% automated and managed with CleanAir Spaces' CAS Dashboard or Comfort Management System.

4. Unit can be integrated with current BMS Systems

ductFIT®|100

ceiling



Air and Surface Disinfection Unit

Designed for areas without air ducts, The ductFIT®100 ceiling can cover up to 100m² with a single unit, it includes its own fan and can operate completely independently from the Air conditioning system. It includes **ductFIT** to eliminate up to 99.9% of all viruses and bacteria and **HEPA filtration** system to eliminate particles and other contaminants.

Description

- Independent air purification system
- Discrete and quiet
- 100 - 270 volt optional installation
- Easy Installation
- Low maintenance

Applications

- Small offices
- Nursing homes
- Hotel rooms, small clubs
- Hospitals
- Gyms

Specifications

- Electrical: 220 V
- Power: <120 W
- Weight: 22 Kg
- Dimensions: 63cm L x 95cm W x 27cm H
- CADR: 800m³/h
- Noise: < 48dB

Installation

CleanAir Spaces' ductFIT®100 Ceiling can be installed in any open ceiling system or it can be ducted and concealed above technical or construction ceiling.

- 1 Unit may be wired into a 220 volt connection.
- 2 The unit needs to be fixed to the ceiling with 4 anchors.
- 3 Unit can work 100% automated and managed with CleanAir Spaces' CAS Dashboard or Comfort Management System.
4. Unit can be integrated with current BMS Systems